



Austram Butterfly Arbor Assembly Tips

It is a good idea when assembling anything to open the box and organize all pieces on a tarp. This helps you identify each part as needed & keeps you from losing small pieces.

You will receive an allen wrench with your arbor. You will also need a utility knife to cut apart the strapping once you open the box.

Insert screws as directed, but do not tighten them until assembly is complete. Assembly will be much easier with a little movement or 'play' at the joints.

To anchor your arbor, place it in the desired area. This area should be fairly level. If not, you will need to make appropriate accommodations to level the arbor during final placement. Mark the footprint of the arbor. Remove the arbor & place the stakes in the area you marked. Drive the stakes into the ground with a rubber mallet. Place the arbor on top of the stakes and used screws provided to secure.

Basic Assembly Procedure

Lay out side panels first, and attach the top panel at a right angle to each side panel using included hardware. Next, attach the 4 arched supports to the corners as directed. With all parts assembled, tighten all screws. Finally, place and anchor your arch and enjoy.

Thank you for purchasing an Austram product. Our products are packaged with complete assembly instructions. If you misplace them or are missing any parts, please contact your retailer.

