

Coco Fiber Template



03061101
Queen Anne Parasol
Wall Pltr.

Amount Needed:

Cut a 36" piece of CoCo Fiber from the 24" wide roll at you local Austram dealer. Position pieces 1 and 2 at bottom of fiber at maximum angle (diagonally across fiber). Piece 3 above.

Recomended Cutting tool:

Barnel Model B1444 Pruner or other good quality staight pruner

