



Austram Roselane Gazebo Instruction Supplement

Before You Begin, Please Note:

Do not tighten ANY screws. Save this for the very last step in the process.

If you have any trouble matching predrilled holes to screws check to make sure that all screws are loosened. It may help to wiggle the pavilion a little while trying to push the screws through the holes.

Two people can assemble the Roselane, but three makes it a lot easier.

Step 1 Establish or create a level area for the base. Screw base together using included screws. Use anchor pins to secure the base to the ground.

Step 2 Make three wall panels using screws provided. (Wall panels consist of 2 pillars (A), one fence (B), and one L type beam (C)). Determine which side of the base will be the door opening. Insert the 1st completed wall panel into the base section directly across from the designated door opening. The next two wall panels will be placed to the right and left of the 1st panel, skipping a base section in between.

Step 3 Join the wall panels using one fence (B) and one beam (D) between panels.

Step 4 Insert inclined frame (E) pieces into top of beam (C&D). Secure the frame (E) together with globe or top frame connector (G).

Step 5 Loosen and turn the clips on each roof frame (E) and remove the brass finial. Insert the roof panel (F). Be sure that the point of the roof panel matches up to the point created by the globe (G). Replace finial and turn the clip to hold roof panel in place (do not tighten). Repeat this step to complete the roof.

With assembly complete, tighten all screws to secure. Decorate with vines, hanging planters, lights, etc, and enjoy. Pavilions are a great way to add character to your garden.